


To prevent the seat from being unstable, please follow carefully the last part of the instructions for the adjustment of the RH mechanism



In the instructions sheet in the last part, under the last image...

... after having adjusted the seat at the desired height you need to block the pivot, by tightening the screw in the positioning groove.



Instead as you can see from the picture all the stools have been tightened with the screw unaligned from pivot groove. Hence the unstable seats.

The correct positioning of the pivot groove is this: aligned to the blockage screw.



Furthermore, if the seat height is adjusted very close to the leg (at the minimum level), the pleated pipe should be removed otherwise it would be ruined by the compression.